


PN


clamp is designed for mounting BTC-20 & BTC-21 series sensor on round cylinder.

**Step 1**


Loosen screw & nut.

**Step 2**

Wrap the band around the cylinder & put the apex through the fastening hole.

**Step 3**

Pull up mounting head & place sensor under the mounting head.

**Step 4**

Swivel set screw to tighten band and fixing sensor. Finally swivel nut for steadying.

PN - S 2 0

S: For cylinder body is stainless steel.



A: For cylinder body is aluminium alloy.

12: ϕ 12 cylinder
16: ϕ 16 cylinder
...
150: ϕ 150 cylinder

EX : PN-S25: It is use on ϕ 25 cylinder and material of cylinder tube is stainless.

PH


clamp is designed for mounting BTC-20 & BTC-21 series sensor on round cylinder. clamp is designed for mounting

**Step 1**


Loosen screw & nut.

**Step 2**

Place sensor & wrap the band around the cylinder, Position the hook with the nearest hole on the band and mark the hole with a permanent marker.

**Step 3**

Remove mounting assembly. Cut the band at the nearest edge of next hole. (the one that's further away from the mounting head).

**Step 4**


Re-place the sensor & mounting assembly. Wrap the band & put the chosen hole on hook. Position the switch and tighten. Finally swivel nut for steadying.

PH - 1 : For ϕ 6 ~ ϕ 63 round cylinder use.

PH - 2 : For ϕ 6 ~ ϕ 125 round cylinder use.

PAB


clamp is designed for mounting BTC-20 & BTC-21 series sensor 12&100 on round cylinder.

**Step 1**


Start by keeping screw 3 to 4 turns into barrel nut on the end of the band assembly.

**Step 2**

Place the screw head into clamp slot and wrap the band around the cylinder. Position the pin with the nearest hole on the band and mark the hole with a permanent marker.

**Step 3**

Remove clamp assembly from the cylinder. Locate the marked hole that fits to the cylinder size, cut the band at midway between the above adjacent hole. (the one that's further away from the screw nut).

**Step 4**

Insert cut end of the band into a flat slot opposite from the clamp slot. Place the chosen hole over the pin and bend the band firmly down with thumb pressure. Then wrap the band around cylinder barrel and re-insert screw head into clamp. Position the switch and tighten.



PAB: For ϕ 12 ~ ϕ 100 round cylinder use.

Unit:mm